




FLOAT 3 - 2.0 ZERO RC

Mounting Orientation for Kit
853-99-114


IMPORTANT: Orienting the shocks improperly can cause interference with the action of the rear suspension resulting in possible loss of control and rider injury or death. If you do not possess the tools or technical knowledge to mount your FOX shocks, have it performed by an authorized dealer.

Remove the rear suspension from the snowmobile. Note the limiter strap and the rear spring preload settings before removing the rear shocks. Mount your FOX shocks as pictured below. When making air pressure adjustments to the front torque arm FLOAT 3 shock, always have the shock fully extended with no weight on the vehicle. FOX FLOAT 3 shock air chambers do come pre-pressurized, it is recommended that you check air pressure on initial setup before riding.




AIR Filler Valve
Preset to **50 PSI**
DO NOT EXCEED 200 PSI


REBOUND ADJUSTER
Preset at **12 Clicks** out
The Rebound Adjuster has a total of 24 clicks, start counting clicks from the adjusters most clockwise limit.



When assembling the lower rear shock pivot use supplied bolt 018-04-038 3/8-24 X 4.5" and quantity (4) 018-05-005-A Washer [.387 ID x1.125 OD X 0.100 TH] (2) per side.



ZERO RC Low Speed Adjusters (LSC) are set at 12 clicks out from bottom. The LSC has a total of 24 clicks. Start counting clicks from the adjusters most clockwise limit.



Install the rear suspension.

Torque all bolts and mounting hardware to the manufacturer's specifications.

Adjust the track tension to the manufacturer's specifications.

Air pressures should always be set at the ambient air temperature anticipated during riding conditions.